


Snow Plow Zone 1

A horizontal scale bar representing 0.8 miles. The scale is marked at 0, 0.2, 0.4, and 0.8. A white segment is positioned between the 0.2 and 0.4 marks.

Map Published: 12/6/2016





Snow Plow Zone 3

0


0.25


0.5

1

Miles

Map Published: 12/6/2016





Snow Plow Zone 4


0


0.25

0.5

Map Published: 12/6/2016







Snow Plow Zone 6

0

0.4


0.8

1.6

Miles



Map Published: 12/6/2016



Snow Plow Zone 7



0


0.45

0.9

1.8 Miles

Map Published: 12/6/2016






Snow Plow Zone 8A/8B

Miles

Map Published: 12/6/2016





Snow Plow Zone 9

0


0.35


0.7

1.4

Miles

Map Published: 12/6/2016





Snow Plow Zone 10

0


0.225

0.45

0.9

Map Published: 12/6/2016






Snow Plow Zone 11

0 0.25 0.5 1 Miles

Map Published: 12/6/2016





Snow Plow Zone 12

A horizontal scale bar representing distance in miles. The scale is marked at 0, 0.25, 0.5, and 1. A white segment of length 0.25 is highlighted.

Map Published: 12/6/2016

